

DEEP WELL PLATES CLEANING

ADAPTED FROM THE BONNET TEAM PROTOCOL REPOSITORY

PROTOCOL:

1. Add bleach in each well for the 96 deep well plate and wait for 1h.
2. Throw away the bleach and clean with water each well twice. Shake the plate to throw away everything correctly.
3. Add ethanol in each well and let it incubate for 30 min.
4. Throw away the ethanol and let it dry on paper.
5. Tape it well with aluminium and autoclave it.