

10x TAE Buffer

Introduction

Recipe for making 10 x TAE buffer

Dont forget to take a part to dilute down to 1 x

Materials

- › 900 mL dH₂O
- › 48.4 g Tris base (Triz)
- › 11.4 mL glacial acetic acid (use lab coat and goggles!!)
 - › Under the fume hood in the back room
- › 3.72 g EDTA
- › Adjust volume to 1L with dH₂O

Procedure